



PM TBW SERVO COVER



PERFORMANCE MACHINE LIMITED WARRANTY INFORMATION

Performance Machine warrants to the original purchaser that the parts of this TBW servo cover to be free of manufacturing defects in materials and workmanship for a period of one (1) year from the date of purchase. In the event warranty service is required, you must call Performance Machine immediately with a description of the problem.

If it is deemed necessary for Performance Machine to make an evaluation to determine whether the part is defective, a return authorization number will be given by Performance machine. The parts must be packaged properly so as to not cause further damage and returned prepaid to Performance Machine with a copy of the original invoice of purchase and a detailed letter outlining the nature of the problem. If after the evaluation by Performance Machine the part was found to be defective it will be repaired or replaced at no cost to you. If we replace it, we may replace it with a reconditioned one of the same design.

Performance Machine shall not be held liable for any consequential or incidental damages resulting from the failure of a Performance Machine part.

Performance Machine shall have no obligation if a part becomes defective as a result of improper installation or abuse.

IMPORTANT NOTICE

Before installing this TBW servo cover, read through these instructions completely; this will familiarize you with the way in which the parts fit together and the tools needed to complete the job.

The PM TBW servo cover involves alterations to your motorcycle and may void your factory warranty. PM **STRONGLY** recommends this installation be done by an experienced motorcycle mechanic.

DISCLAIMER

These Performance Machine parts are designed for high performance motorcycle applications and are intended for the very experienced rider only. The installation of these Performance Machine parts may adversely effect or void your factory warranty.

1. Turn off your motorcycle and place securely on a lift or the sidestand.
2. Remove the complete air cleaner assembly.
(Refer to your HD service manual for additional instructions)
3. With the air cleaner removed locate the throttle by wire servo wire harness towards the rear of the throttle body. Use the supplied zip tie to fasten the wire harness to the harness plug. This will create a cleaner look by hiding the harness. Clip the zip tie once it is fastened.



CONTINUED ON PG 2



PERFORMANCE MACHINE TBW SERVO COVER INSTALLATION (CONTINUED)

4. Reinstall the air cleaner placing the gasket on the throttle body side of the TBW servo cover plate. Use the air cleaner backing plate bolts to hold the complete assembly together during installation. Torque the 1/4-20 x 3/4" socket head bolts to 8 ft-lbs and torque the breather bolts to 15 ft-lbs. (Refer to your HD service manual for additional instructions)




5. Finish installing the complete air cleaner.

Disclaimer: The PM TBW servo cover is compatible with many air cleaners on the market so during reassembly follow the specific manufacturers instructions for your specific air cleaner.



6. Hit the road!



ITEM NO.	DESCRIPTION	QTY.
1	THROTTLE SERVO MOTOR BRACKET	1
2	ZIP TIE .19" X 7-1/2" BLACK NYLON	1

CONTACT INFORMATION

Performance Machine
6892 Marlin Circle
La Palma, California
90623 - USA
Toll Free: 800-479-4037
Direct: 714-523-3000
Fax: 714-523-3007
Email: tech@performancemachine.com
Website: performancemachine.com